

**Material:** Food-safe Solid Composite  
**Size:** 17-1/4" (length) x 7" (width) x 3/8" (thick)  
**Compatible Ruvati Sinks:**

RVG1302, RVG1306, RVG2302, RVG2306, RVH5003, RVH6222, RVH6333, RVH6527 RVH6530, RVH6533, RVH8002, RVH8003, RVH8023, RVH8030, RVH8035, RVH8036, RVH8222, RVH8224, RVH8300, RVH8301, RVH8307, RVH8308, RVH8309, RVH8310, RVH8320, RVH8324, RVH8253, RVH8255, RVH8277, RVH8299, RVH8300, RVH8301, RVH8303, RVH8304, RVH8307, RVH8308, RVH8309, RVH8310, RVH8320, RVH8324, RVH8327, RVH8333, RVH8335, RVH8341, RVH8345, RVH8350, RVH8351, RVH8356, RVH8359, RVH8424, RVH8433, RVH8555, RVH8570, RVH8573, RVH8582, RVH8584, RVH8591, RVH8596, RVH8597, RVH8630, RVH8633, RVH8666, RVH9020, RVH9050, RVH9100, RVH9106, RVH9200, RVH9201, RVH9207, RVH9222, RVH9300, RVH9301, RVH9308, RVH9333, RVL2387, RVU6320, RVU6321, RVU6327, RVU6421, RVU6425

## CARE INSTRUCTIONS



**Cleaning:** Hand wash the plastic cutting board with soap and hot water or run it through the dishwasher.



**Disinfecting:** You can disinfect the board by soaking it for 2 minutes in a solution of two teaspoons of bleach and one gallon of water.



**Deodorize:** Wet the board and sprinkle it with baking soda. Let it stand for a few minutes then rinse it in water.



**Scratches:** It is normal for plastic cutting boards to take knife marks. The scratches will be noticeable when the board is new. Over time, they will blend in.



**Heat:** Do not expose the cutting board to hot surfaces, or put in an oven or microwave. It can cause the board to melt.

